


POST IN CHANGEROOM OPERATING AND SERVICE INSTRUCTIONS



Moore LOCKERBASKETS are furnished in your changeroom to provide 100% ventilation for the drying and ventilation of damp clothing to insure your health and comfort. If you have any suggestions on how we can improve our system, please contact us at the address below.




1



LOWERING LOCKERBASKET

- Remove lock.
- Grasp cable and chain just above and below the locking plate and rotate the locking plate 90 degrees, then remove the locking plate from the locking bolt by sliding it past the eye of the locking bolt.
- Place your other hand on the chain and firmly hold the chain with both hands.
- Lower the LOCKERBASKET slowly and safely.

2



CLOTHING STORAGE

- Place helmet, shoes and personal items in the basket.
- Hang trousers, shirts, jackets on garment hooks or hanger.
- Do not overload basket. Maximum load 14 kg (30 lbs).



3



ELEVATING LOCKERBASKET

- Grasp chain with both hands.
- Raise slowly.
- While firmly holding the chain with one hand, grasp the cable with the other hand and rotate the locking plate 90 degrees and

slide the locking plate on to the locking bolt past the eye until the locking plate is able to rotate into the vertical position. Lock for security.

CLEANING

Locking rail and Bench units should be cleaned with mild commercial detergent, water and a soft brush or cloth. Hose or rinse with clean water after washing. LOCKERBASKETS and chain may be cleaned in the same manner, as conditions require.

DISTRIBUTOR

CAUTION
DO NOT STORE TOOLS OR EQUIPMENT IN OR
HANGING FROM LOCKERBASKETS UNLESS THEY
ARE SECURELY FASTENED TO THE BASKET.



P.O.Box 3750 • Charleston, WV 25337-3750 USA
Phone 304.344.8024 • Fax 304.344.8025
E-mail <http://www.morco.com>

INSPECTION AND MAINTENANCE

Periodically inspect the complete Overhead Clothes Storage System, checking the condition of the cable and chain, tightness and alignment of the Locking Bolt, operation of the pulley sheaves and the tightness and condition of all other bolts and cable fittings.

Replace worn or damaged parts. Free replacement parts list is available from The Moore Company.